

VIPP 4 SPARE TOILET ROLL HOLDER



Standard brick/concrete rawplugs enclosed

Please make sure to choose rawplugs according to the material on which you want to place the product. Substitute enclosed rawplugs with another type if needed.



Drill size: \varnothing 6mm



Drilling distance: 12mm

Mounting instructions

①

Drill holes and place rawplugs.

② ③

Mount the bracket using screws.

④

Loosen the integrated screw on the product with the allen wrench. Then place the product onto the bracket.

⑤

Tighten the integrated screw on the product with the allen wrench.

