



# VIPP 3 TOILET ROLL HOLDER

vipp



## Standard brick/concrete rawplugs enclosed

Please make sure to choose rawplugs according to the material on which you want to place the product. Substitute enclosed rawplugs with another type if needed.



Drill size:  $\varnothing$  6mm



Drilling distance: 120mm

## Mounting instructions

①  
Drill holes and place rawplugs.

② ③  
Mount bushings using screws.

④  
Loosen the integrated screws on the product with the allen wrench. Then place the product onto the bushings.

⑤  
Tighten the integrated screws on the product with the allen wrench.

