



vipp



**CONGRATULATIONS ON YOUR NEW
VIPP OPEN-AIR COFFEE TABLE Ø90**

*Whether we develop a bin, rethink
the modular kitchen, or create a furniture
line, we measure the quality of our products
on their ability to stand the test of time.
A recipe we have followed since 1939.*

KASPER EGELUND, CEO AND 3RD GENERATION VIPP OWNER

VIPP HEADQUARTERS
Snorresgade 22 | 2300 Copenhagen S | Denmark
+45 4588 8800 | info@vipp.com

VIPP STUDIO USA
+1 917 580 2148 | vippusa@vipp.com

VIPP.COM | @VIPP

VIPP714

Open-Air Coffee Table Ø90

PRODUCT DESCRIPTION



Slim teak lamellas placed in a graphic pattern make up the tabletop covering the three-legged aluminium frame of the larger coffee table in the Vipp Open-Air collection. Modelled to be combined with the smaller Ø60 coffee table, it can either stand alone or accommodate a larger outdoor lounge setting with a complete table composition in complementing materials.

Materials

Powder-coated aluminum with outdoor coating, tabletop of teak.

PRODUCT DIMENSIONS


H. 42.5 cm / 16.7 in, Ø. 90 cm / 35.4 in.



ASSEMBLY GUIDE

Please follow the assembly guide to ensure correct installation.

1. When assembling your table, place it upside down on the cardboard or another soft underlay to prevent scratches or marks, and to protect the floor. Do not place the table on its sides.
2. Mount each leg (1), and tighten the screws (2).
3. Place tabletop on the frame so it is aligned correctly with all legs.



If you experience problems, please do not hesitate to contact our Customer Service at info@vipp.com.

CARE INSTRUCTIONS

We recommend caring for the tabletop to ensure its long-lasting appeal and appearance.

Teak wood

Teak will over time patina as it weathers.

Use a brush to remove any built-up dirt from the surfaces. Make sure to follow the natural grain direction to avoid scratches. Carefully dampen the teak surfaces with clean water and a lint-free cleaning cloth. Use a teak cleaner and evenly wash all surfaces with a soft cloth. Follow the instructions of the teak cleaner before cleaning it; use a sponge in the grain direction to avoid scratches. Lightly rinse surfaces with clean water and allow it to dry.

Powder-coated surfaces

Keep powder-coated surfaces clean and dry. Use a lint-free cleaning cloth or a soft brush with warm water and a mild detergent. Finish by wiping down the surface with a dry cloth.

Read more about care instructions on vipp.com.

WARRANTY

Vipp offers warranty on products according to national laws and regulations. The warranty does not cover defects or damage caused directly or indirectly by misuse or poor maintenance, violence or manipulation. The warranty presupposes rightful use as described in Vipp's care instructions, which can be found in this folder or under the specifications of each product at vipp.com. In case of a defective product, please contact your place of purchase.